

U SHAPED FULL BED
FITTING OF BED IN VAN

FITTING OF BED

POSITION OF BED SHOWN IS IN
RESPECT OF A T5 LWB OR SWB
VAN. ENSURE BED WILL FIT IN YOUR
VAN. EACH OF THE THREE SECTIONS
SHOULD BE SECURED WITH AT LEAST
4 X M12 BOLTS AND NYLOC NUT
TOGETHER WITH THE 40 X 40 ANGLE
BRACKET SUPPLIED.



PLAN VIEW OF BED IN VAN

